



LE CYLINDER
"VERSION V1 ET BLE "

Manuel de démarrage rapide | Schnellstart-Anleitung | Quick Start Guide




Figure 2



Using *LE CYLINDER* for the first time : (see figure 2)

- a) Remove the watch holder (1) by unclipping it in line with LE CYLINDER.
- b) Using the special tool provided (2), unscrew the central screw (3) as shown.
- c) Remove the cover (4).
- d) Insert 4 AA lithium/alkaline 1.5V (LR6) batteries in the housings (5), respecting the polarity
(Check the markings on the battery housings.)
- e) Replace the cover (4) carefully.
- f) Replace the central screw using the special tool.
- g) Ensure that LE CYLINDER turns freely.
- h) Press the button on the front to ensure that the device is charged and to start the cycle.

(N.B. The cycle will only begin if there is a watch on the watch holder)

Charge : The light flashes to indicate the level of charge.

- 4x Fully charged
- 3x > 60% charge
- 2x > 30% charge
- 1x **Replace the batteries !**



LE CYLINDER is supplied pre-configured, meaning that in the majority of cases it is operational without the user needing to change any settings.

The pre-defined cycle is set as follows :

- 8 turns anti-clockwise
- 8 turns clockwise
- 15 minute wait
- 8 turns anti-clockwise
- 8 turns clockwise

VERSION BLE

Please install the free provided App allowing the configuration and battery status check here :

iOS :

<http://itunes.com/apps/sdataway/cylinder>



Android :

<https://play.google.com/store/apps/details?id=com.sdataway.cylinderble>



VERSION V1

The application allows the configuration with PC or Mac

Can be downloaded at: www.apk-cylinder.ch



info@apk-cylinder.ch – www.apk-cylinder.ch